



**SEASONAL
LIVING®**

Caring for Your Fizz Collection Products

The **Seasonal Living Fizz Collection** is upholstered furniture designed for outdoor and indoor use. Made in the U.S., the collection's fast-drying cushioning is made from thick foam cores topped with contouring foam for long-lasting shape. Anti-microbial seat cushions are laminated with water barriers and placed into zippered, non-woven, water-repellent covers prior to being covered with the fabric of your choosing. Furniture frames are marine-grade plywood or in some cases metal. Follow these directions to protect your furniture and keep it looking fresh.

Features

- Furniture frames are constructed of marine-grade plywood, galvanized steel, stainless steel, powder-coated aluminum, or zinc-plated metal.
- Interlocking frame components are glued with eco-friendly water-based, low-VOC adhesives and stapled with surgical stainless-steel staples.
- Nylon glides, galvanized connectors, and rust-free staples are weather-resistant.
- Sytex webbing suspension and non-shrink, UV-protected thread ensures high outdoor performance.
- Upholstery and cushion covers are constructed of 100% solution-dyed acrylic or spun. Polypropylene yarns from the Seasonal Living collections.
- Upholstery materials are fitted and tailored to the furniture frame. They are not designed to be removed.

We Recommend

- Do not climb, stand, or jump on or off furniture. Do not sit on tables, chair arms, or seat backs. Chairs and stools are designed for seating only one person at any time. Never use furniture as a stepladder.

Continued on next page

SeasonalLiving.com

Tel 512-554-5738

Fax 512-681-9188

sales@SeasonalLiving.com

Seasonal Living

Park Tower, Suite 350

4009 Banister Lane

Austin, Texas 78704

United States of America

Caring for Your Fizz Collection Products

- Tables are not designed to support human weight or loads over 60 pounds.
- Do not lean back or rock on rear legs of a chair. Chairs must have four legs on the ground during use.
- We recommend that upholstered furniture is placed in a sheltered outdoor location. Technically, the product is designed for full outdoor use, however, for better performance and appearance, we strongly recommend sheltered outdoor locations.
- Do not allow furniture to be immersed in or stand in pools of water.
- When not in use, we recommend the use of breathable, high-quality furniture covers to protect furniture during wet periods and when not in use. Do not enclose furniture in plastic or non-breathable materials, to prevent mildew and mold from forming.
- If furniture does become wet, move to a well-ventilated space, or add a large fan nearby to reduce drying time.
- Do not sit on furniture backs or arms and do not store furniture with heavy weights on it. Weight will flatten and create depressions in the upholstery and foam.
- Keep children from playing on or around furniture and packaging materials.
- Do not lift pieces of furniture alone. Always get adult assistance to unpack, assemble, set up, and move any piece of furniture.
- Do not leave sun or reading glasses on upholstery or cushions outdoors. They can magnify sunrays and burn the fabric.
- Regularly inspect all furniture for pests, animals, or insects, as well as for tears or cuts.
- Never drag furniture across a floor or surface and do not pull furniture by the upholstery.
- Never modify any part of the furniture without manufacturer's written approval. Doing so will void the Limited Manufacturer's Warranty.

Care of Cushion Upholstery and Cushion Covers

- Regularly brush or vacuum loose dirt from all sides of the furniture, including the undersides.
- Avoid acidic or oily substances from coming into contact with upholstery and cushion covers.
- Never place fabrics in the dryer.
- Lightly clean with a solution of 1/4 cup mild soap, such as Woolite or Dawn (non-dyed) dishwashing liquid, per gallon of lukewarm water.
- Use a sponge or soft-bristle brush to clean. Allow cleaning solution to soak into fabric. Rinse thoroughly to remove all soap residue.
- Allow fabric to air dry.
- To spot clean, apply a light mist of mild soap and water using a spray bottle. Work the solution into the stain by lightly scrubbing the area with a sponge or soft-bristle brush. Rinse thoroughly to remove all soap residue. Repeat until all soap residue is removed. Wet-vacuum or blot excess water and allow to air dry.

Continued on next page



[SeasonalLiving.com](https://www.seasonalliving.com)

Tel 512-554-5738

Fax 512-681-9188

sales@SeasonalLiving.com

Seasonal Living

Park Tower, Suite 350

4009 Banister Lane

Austin, Texas 78704

United States of America

Caring for Your Fizz Collection Products

Removable 100% Solution-Dyed Acrylic Fabric

- To wash by hand, soak fabric in a solution of 1/4 cup mild soap per gallon of lukewarm water. Use a sponge or soft-bristle brush to clean. Rinse thoroughly to remove all soap residue. Allow fabric to air dry.
- To machine-wash, wash in cold water using normal amounts of mild laundry detergent and add 1 cup of bleach. Allow fabric to air dry. Do not place in a dryer.

Heavy Cleaning

100% solution-dyed fabrics do not promote mildew growth. However, mildew can grow on dirt or foreign substances that are not regularly removed from the fabric. To clean stubborn stains:

- Cover or otherwise protect the area around your fabric when using a bleach solution.
- Prepare a solution of 1 cup of bleach and 1/4 cup mild soap per gallon of water.
- Spray on entire area and allow to soak into the fabric for 15 minutes.
- Remove stain with a sponge, clean towel, or very soft bristle brush.
- Rinse thoroughly to remove all soap and bleach residue.
- Allow fabric to air dry.
- If stain and/or mildew are severe, increase the quantity of bleach used.
- Test cleaning solution on an inconspicuous area first and allow to dry before applying cleaning solutions.

Re-Treating Fabric

Many solution-dyed fabrics are treated with a fluorocarbon finish for water repellency. After a thorough cleaning or after five years of use, water repellency should be replenished. We recommend 303 Fabric Guard™.

- Clean fabric using one of the cleaning methods above. Allow fabric to air-dry completely.
- Apply 303 Fabric Guard in a well-ventilated area, following directions on the container.
- Apply a thin, even coating and allow fabric to dry completely.
- Apply a second thin, even coating and allow to dry. Two light coatings are more effective in restoring water resistance than a single heavy coat. A 15-ounce bottle covers up to 50 square feet of fabric.

Professional Cleaners

Do not dry-clean 100% solution-dyed fabrics. Be sure to inquire about a professional cleaner's experience in working with outdoor fabrics before allowing them to clean your furniture.



SeasonalLiving.com

Tel 512-554-5738

Fax 512-681-9188

sales@SeasonalLiving.com

Seasonal Living

Park Tower, Suite 350

4009 Banister Lane

Austin, Texas 78704

United States of America